



DB114/RTK Operating Instructions



Deploying the bollard:

1. Insert the T-handle lifting key into the grooves on top of the bollard stem
2. With lifting key in vertical position lift bollard from sleeve
3. Bollards will automatically lock in when the deployment height is reached.
4. Remove lifting key

Remember: use a good lifting technique, bending the knees and keeping a straight back.



To retract the bollard:

1. Insert the T-handle lifting key into the grooves on top of the bollard stem
2. Insert the locking lock key
3. Apply slight upward pressure with lifting key and turn locking key in clockwise direction
4. Lower the bollard slightly below it's fully retracted height before removing locking key
5. Once locking key is removed, lower bollard gently into sleeve

Warning: Do not let the bollard freely drop into sleeve, always lower gently using the lifting key.

